




Static Var Generator User Manual

ELPQC-SVG-4005 Series

Model: ELPQC-SVG-4005



Rated Voltage: $400V \pm 15\%$

Rated Frequency: 50Hz

Version: V664

Web: www.elcosine.com

E-mail: elcosine.solar@gmail.com



ELCOSINE ENERGIA PVT. LTD.

@All rights reserved, including but not limited to the application ownership.

At the same time, our company reserves the right to investigate the responsibility for acts of reproduction, transmission, dissemination without our permission.



Safety Instructions (DANGER)

1. The contents of this manual involve the installation and use of the comprehensive power quality control device (hereinafter referred to as the device), and the manual shall be read before installation.
2. The instructions are very important for users and the device. Ignoring them may cause serious damage to you and the device.
3. This device must be commissioned and maintained by our company or the engineer designated by its dealer; otherwise it may endanger personal safety and lead to the malfunction of the device, and the damage caused to this device thereby shall not be under warranty.
4. Only qualified personnel shall be allowed to operate the device, including installation, running, routine maintenance, removal, etc. The operation of the device by other personnel, except technical personnel of the company and qualified users, is strictly prohibited.
5. Before the power is on, confirm that the device has been properly grounded. Poor grounding will easily lead to abnormal operation of the device and danger of electric shock.
6. When this device is disconnected from the power grid, it cannot be opened until at least 5 minutes later when the residual voltage of the DC capacitor of the energy storage unit inside the device is released; otherwise there will be risk of electric shock.
7. All electrical installation and routine maintenance must be carried out when the power is off.
8. Please do not try to maintain the device when it is running.
9. Electric shock may be deadly. Please do not touch live parts.
10. Arc sparks may hurt eyes, burn skin, damage this device and ignite explosive objects.
11. Prevent short circuit caused by tools during the process of installation and operation of this device. Be well prepared for taking safety protection measures.



Notes (Warning)

Make sure to read these warnings before installing and using this device.

1. This device is only for commercial / industrial purpose and cannot be used as an equipment associated with life support equipment.
2. After the installation of this device is completed, this device and its components cannot be moved or removed without the operation of the professional personnel of the company. It can only be operated within the operating range signed in the technical agreement and cannot be used for other purposes.
3. Please use and operate the device strictly in accordance with the electrical wiring diagram of the device provided by our company and the instructions in this manual, so as to prevent the device from being damaged and personal injury.
4. In the live line connection of the current transformer, first of all, make sure that its secondary side is in a short circuit state. The secondary side of the current transformer in operation shall not be disconnected.
5. Improper ventilation or poor heat dissipation will lead to overheating, causing damage to the device. It is not allowed to cover the vent of the device and ensure that it is far away from the heat source. The fan of this device shall be started normally. There shall be no abnormal phenomenon in operation, such as abnormal halt and abnormal noise, so as to ensure good heat dissipation of the device (Let cold air in in the front and hot air out on the back.).
6. This device shall be used in an environment free of conductive dust and corrosive substances.
7. In maintenance, make sure that the power of the equipment has been cut off and the operator has a safety watcher.
8. This device conforms to CE73 / 23 & 93 / 68 (low voltage safety) and 89 / 336 (EMC), and its installation and use shall comply with the above requirements and the accessories designated by the manufacturer shall be used, otherwise, it will be deemed to automatically give up the quality assurance of the company.
9. **Mark:** The product model, factory SN, capacity, weight and production date of the device are indicated on the nameplate. Please confirm the specification of the equipment when using it.
10. **Transportation:** During transportation, make sure that the stress direction of the device is consistent with the fixed direction, and it cannot be placed upside down or sidelong. Prevent it from direct physical impact and vibration, from rain and water immersion, from burning by high temperature, and from corrosion by salt fog.

11. Receiving and inspection of equipment: This device has been thoroughly tested and inspected before being delivered, and the transportation preparation has been made according to the requirements of safe transportation. However, during long-distance transportation, the retaining elements of the device may still become loose due to vibration and bump. Therefore, please check as follows after receiving the device:

- a) Visually inspect whether the packaging box transported is damaged or not. In case of any damage, request the forwarding agent to check the transportation situation and record the damage on the transport receipt.
- b) Try to be careful when disassembling the packaging box. If the packaging box is to be disassembled with bars or hammers, please be careful to avoid damage to the device.
- c) Visually inspect that there is no external damage on the device, such as scratch, paint-shedding, sinking, etc. Check for loose components and wiring. If there is damage during transportation, please contact us.
- d) Carefully check the delivery note to ensure that the model and quantity of the goods are correct. If you have any questions, please contact us at the first time.

12. Storage: make sure to prevent it from direct physical impact and vibration, from rain and water immersion, from burning by high temperature, and from corrosion by salt fog, from being stored in a dusty environment during storage. The packaging of this device can be stored indoors for 6 months (starting from the date of delivery). The warehouse shall be kept dry and ventilated with no corrosive substances, no strong mechanical vibration, impact and the action of a magnetic field.

13. Long term storage: If the storage time of your device exceeds one year, the electrolytic capacitor shall be recharged. If it is not recharged, the electrolytic capacitor may be damaged so that the device cannot work normally.



Notes (Warning)

Dangerous voltage: All operations (including opening the housing of this device, removing or installing connecting cables) can only be done by professionals.

Security: The grounding terminals on this device must be reliably grounded. Request the qualified electrical engineer to confirm that the device is fully grounded.

Contents

CHAPTER I SVG DESCRIPTION	2
13.1 INSTRUCTION TO SVG.....	2
<i>13.1.1 SVG Features</i>	<i>2</i>
<i>13.1.2 Device Parameters</i>	<i>2</i>
13.2 APPEARANCE AND INSTALLATION DIMENSION	3
13.3..... TECHNICAL DATA	5
CHAPTER II INSTALLATION AND ELECTRICAL CONNECTION	6
2.1 INSTALLATION INSTRUCTIONS	6
2.2 REQUIREMENTS FOR VENT	8
2.3 PRIMARY AND SECONDARY INTERFACES OF SVG	8
<i>2.3.1 Location of Primary and Secondary Terminals of SVG</i>	<i>9</i>
<i>2.3.2 Model Selection Table of Power Distribution Cable of SVG</i>	<i>9</i>
<i>2.3.3 Fuse Protection of Input End of SVG</i>	<i>10</i>
<i>2.3.4 Description of Secondary Terminals of SVG</i>	<i>10</i>
<i>2.3.5 Connection Diagram of Secondary Terminals of SVG</i>	<i>14</i>
2.4 PANEL INDICATOR LIGHT AND DEBUGGING INTERFACE OF SVG	23
2.5 EXTERNAL LCD SCREEN OF SVG	23
CHAPTER III COMMISSIONING INSTRUCTIONS OF THE DEVICE	24
3.1 START AND SHUTDOWN OF THE DEVICE	24
<i>3.1.1 Starting Mode</i>	<i>24</i>
<i>3.1.2 Starting Steps</i>	<i>24</i>
<i>3.1.3 Shutdown Mode</i>	<i>24</i>
3.2 DISPLAY INTERFACE OF THE DEVICE	25
3.3 PILOT RUN STEPS	25
<i>3.3.1 Inspecting Items</i>	<i>25</i>
<i>3.3.2 Start of the SVG</i>	<i>25</i>
<i>3.3.3 Observation of Compensation Effect</i>	<i>25</i>
CHAPTER IV COMMUNICATION PROTOCOL	26
4.1 COMMUNICATION SETTINGS	26
4.2 DATA TYPE	26
4.3 FUNCTION CODES	26
4.4 COMMUNICATION PROTOCOL	27
CHAPTER V REPAIR AND MAINTENANCE	29
5.1 ROUTINE MAINTENANCE	29
5.2 PRECAUTIONS	29
5.3 FAULT JUDGEMENT	29
APPENDIX 1 HORIZONTAL RACK MOUNT SVG	30
APPENDIX 2 WALL MOUNT SVG	32

Chapter I SVG Description

1.1 Instruction to SVG

1.1.1 SVG Features

- SVG can dynamically and smoothly compensate inductive and capacitive reactive power, and the power factor of the system after compensation is greater than 0.98;
- Fast response
- High controllability
- Automatic current limiting function and
- No overload;
- Modular design, a variety of installation methods, such as rack-mounted type and wall-mounted type, etc., and multiple devices can operate in parallel, so as to meet the actual needs to the greatest extent.
- Multiple protection against over-current, over-voltage, over-temperature, phase sequence error and default phase, etc.
- It is configured with RS485 and CAN standard communication interfaces, which can make it exchange information with other unit devices, and it can also be configured with wired / wireless communication modules to realize remote data monitoring.
- If Clients need harmonics control, and 3 phase load balancing, please refer to our Comprehensive power quality control device (Advance Static Var Generator, Active Power Filter).

1.1.2 Device Parameters

- Rated voltage: AC 400V $\pm$ 15%
- Operating frequency: 50Hz $\pm$ 2.5Hz
- Module capacity: 20kvar, 30kvar, 50kvar, 75kvar, 100kvar
- Parallel connection of multiple machines: Up to 10 sets can be connected in parallel
- Response time: $\leq$ 5ms
- Efficiency of single machine: $\geq$ 97%
- Main circuit structure: Three-phase four-wire
- Circuit topology: Three-level structure
- Display Interface: External LCD screen
- Display status: Displayed in a data mode
- Operations: Manual start, automatic start
- Communication: RS485, Modbus communication protocol

- Environment temperature: - 20 ~ 55 °C (rated power output)
- Storage temperature: -30~70°C
- Relative humidity: 95 % at a maximum, no condensation
- Altitude: Below 1500 meters above sea level
- Cooling requirements: It requires well ventilation, and the air vent can be opened through the cabinet door, or a fan can be installed in the cabinet.
- Working mode: Reactive power compensation, load imbalance compensation
- Current limit: The compensating current is automatically limited within the Rated.

1.2 Appearance and Installation Dimension

The device capacity is divided into 20kvar, 30kvar, 50kvar, 75kvar, 100kvar. And each device can be operated in any parallel combination. Please refer to the following figure for specific external dimensions.




Figure 1 - 1 Overall Dimension Drawing (Unit: mm) of SVG/20-Rack Type




Figure 1 - 2 Overall Dimension Drawing (Unit: mm) of SVG/30(50)-Rack Type




Figure 1 - 3 Overall Dimension Drawing (Unit: mm) of SVG/75(100)-Rack Type

1.3 Technical Data

Table 1-1 Technical Data

Rated capacity	20kvar	30kvar	50kvar	75kvar	100kvar
Rated current	30A	50A	75A	100A	150A
Cooling mode	Air cooling				
Environment temperature	-20~55℃				
Parallel operation	When multiple devices are running in parallel, refer to Table 2-9 for the selection of transformer and 2.3.5 for the connection method.				
Current transformer	50:5~10000:5				
Power consumption	≤3% of rated capacity				
Requirements for air volume	≥180m ³ /h	≥200m ³ /h	≥350m ³ /h	≥500m ³ /h	≥800m ³ /h
Grid frequency	50Hz±5%				
Grid voltage	400V±15%				
Connection mode	3phases+N+PE				
Protection grade	IP30				
Dimension	Refer to 1.2 and Appendix				
Weight	18kg	20kg	26kg	48kg	55kg

Notes: Devices at 480v level voltage are as follows

Rated capacity	20kvar	30kvar	50kvar	75kvar	100kvar
Rated current	24A	36A	60A	90A	120A

Chapter II Installation and Electrical Connection


2.1 Installation Instructions

Table 2-1 Installation Space of SVG

Position	Requirements for Installation Space
Front end (air inlet)	≥ 100 mm, or a vent is made at the air inlet of the corresponding module of the cabinet
Rear end (air outlet)	≥ 200 mm, or a vent is made at the air inlet of the corresponding module of the cabinet

Note: If the depth of the cabinet cannot meet the minimum requirement for installation space, air holes of the same size must be made at the inlet / outlet of the corresponding module on the front and rear cabinet doors of the cabinet. Please do not add filter cotton to the air holes.

The conventional mode of the device is a rack-mounted type, which is installed horizontally in the cabinet and fixed by 4 location holes. Refer to Figure 2-1 for the installation mode. (Note: **If you need vertical installation or wall-mounted installation, please contact the technical support or sales personnel of the company.**)






Figure 2-1 Rack Installation Diagram of Devices (50A/ 35kvar, 75A / 50kvar)




Figure 2-2 Rack Installation Diagram of the Device (100A/75kvar)

2.2 Requirements for Vent

Power-type power electronic components are used in the device, which will generate a large amount of heat during operation. In order to ensure the normal and reliable operation of the device, the cabinet must have good measures for ventilation and heat dissipation.

When the centralized panel is installed in the device, the requirements of the cabinet for heat dissipation are as follows:

- (1) The front and rear doors of the cabinet must be provided with air holes, for which the requirements are as follows:
 - With respect to holes for the front panel of the cabinet corresponding to the front air inlet of the device, their area shall be no less than that of the front air inlet of the device;
 - With respect to holes for the rear panel of the cabinet corresponding to the rear air outlet of the device, their area shall be no less than that of the front air outlet of the device;
 - Filter cotton cannot be added to the air holes, so as to prevent dust, impurities, etc. from blocking the air holes.
- (2) If the cabinet is equipped with ventilation and heat dissipation, such as fans, the air volume requirements of a single device are as follows:

Table 2-2 Requirements for Air Volume of Ventilation

Capacity	Air Volume Requirements
20kvar	$\geq 180\text{m}^3/\text{h}$
30kvar	$\geq 200\text{m}^3/\text{h}$
50kvar	$\geq 350\text{m}^3/\text{h}$
75kvar	$\geq 500\text{m}^3/\text{h}$
100kvar	$\geq 800\text{m}^3/\text{h}$

2.3 Primary and Secondary Interfaces of SVG

DANGER



Dangerous voltage:

Short circuit and electric shock caused by ungrounded connection or a contact with liquid can lead to fatal danger.

It must be ensured that this device module is grounded.

It is not allowed to assemble this device in an environment with liquid.

It is not allowed to expose this device to an environment with condensation.

The cover / door can only be removed or opened under the condition that this device is completely powered off and the capacitor has sufficient time (no less than 5 minutes) for discharging.

2.3.1 Location of Primary and Secondary Terminals of SVG




Figure 2-3 Terminal Position Diagram of Devices (20kvar, 30kvar, 50kvar)




Figure 2-4 Terminal Position Diagram of Device (75kvar, 100kvar)

Note: All devices with different capacities are identical in terminal sequence and definition, and only slightly vary in the position and size of A(L1)/B(L2)/C(L3)/N main terminals.

2.3.2 Model Selection Table of Power Distribution Cable of SVG

SVG has five external power terminals. Please refer to Table 2-3 for Model Selection of Cables.

- Input A - Phase A input end of mains supply
- Input B-Phase B input end of mains supply
- Input C-Phase C input end of mains supply
- Input N-Zero line input end of mains supply
- Input N-Zero line input end of mains supply

Table 2-3 Model Selection Table of Device Cables

Item	Parameter Requirements			
CT ratio range	50:5~20000:5			
CT cable	CT rated load	Cross sectional area of cables	Length of one-way connection	
	5VA	2.5mm ²	≤10m	
		4.0mm ²	10~20m	
	10VA	2.5mm ²	≤20m	
		4.0mm ²	20~40m	
	15VA	2.5mm ²	≤30m	
		4.0mm ²	30~60m	
Power cable (A/B/C/N/PE)	Capacity	A/B/C	N	PE
	20kvar	12mm ²	2x12mm ²	16mm ²
	30kvar	16mm ²	2x16mm ²	16mm ²
	50kvar	25mm ²	2x25mm ²	16mm ²
	75kvar	35mm ²	2x35mm ²	16mm ²
	100kvar	50mm ²	2x50mm ²	25mm ²
	If there is a requirement for cable temperature, a higher specification of the cable is needed. If ASVG(require harmonics control),it requires higher cable specs.			

2.3.3 Fuse Protection of Input End of SVG

It is recommended to install fuses at the inlet of SVG for protection.

Table 2-4 Recommended Fuse Parameters Table

Rated capacity of the module	20kvar	30kvar	50kvar	75kvar	100kvar
Rated current of the fuse	60A	80A	100A	125A	160A
Fuse type	Fast fuse	Fast fuse	Fast fuse	Fast fuse	Fast fuse

2.3.4 Description of Secondary Terminals of SVG




Figure 2 - 5 Definition of Secondary Terminal

Table 2 - 5 Description of Port 1 of Secondary Connection

SN	Mark	Description	Remarks
1	485A1	No.1 RS485 Port A	RS485 in Line 1 (It is standby, which can be connected to the intelligent capacitor or the RS485 port of other device.)
2	485B1	No.1 RS485 Port B	
3	485A2	No. 2 RS485 Port A	485 Port in Line 2 (parallel operation of modules, LCD screen, HMC panel)
4	485B2	No. 2 RS485 Port B	
5	CANL	CANL	CAN communication interface (standby)
6	CANH	CANH	

Table 2 - 6 Description of Port 2 of Secondary Connection

SN	Mark	Description	Remarks
7	COM+	DC24V+	DC power output: 24V, power: 25W power, which can be used as the power supply of external LCD or other controller
8	COM-	DC24V-	
9	DI1	Start signal of the Device (remote signal input)	DI1 and COM- are connected to normally open inching button.
10	DI2	Shutdown signal of the Device (remote signal input)	DI2 and COM- are connected to normally closed inching button.
11	YK1	Operation instruction of the Device (relay output)	YK1 and COM- are connect with 24V DC indicator light, which is on when running.
12	YK2	Failure instruction of the Device (relay output)	YK2 and COM- are connect with 24V DC indicator light, which is on when it breaks down.

Table 2 - 7 Description of Port 3 of Secondary Connection

SN	Mark	Description	Remarks
1	IA+	Phase A S1 terminal of system / load current transformer	Sampling transformer input signal, also known as external CT current input signal, of which the CT can be installed on the load side or system side, and it is preferred to install it on the load side in design.
2	IA-	Phase A S2 terminal of system / load current transformer	
3	IB+	Phase B S1 terminal of system / load current transformer	
4	IB-	Phase B S2 terminal of system / load current transformer	
5	IC+	Phase C S1 terminal of system / load	

		current transformer	
6	IC-	Phase C S2 terminal of system / load current transformer	

Table 2 - 8 Description of Port 4 of Secondary Connection

SN	Mark	Description	Remarks
1	GIA+	Phase A S1 terminal of current transformer in the compensating cabinet	When a single module works, the signal does not need to be connected; When multiple modules are used in parallel or capacitors are used for compensation, a measuring transformer must be installed. The internal CT measures the total output current of the compensation cabinet (the compensating current of all modules and capacitors).
2	GIA-	Phase A S2 terminal of current transformer in the compensating cabinet	
3	GIB+	Phase B S1 terminal of current transformer in the compensating cabinet	
4	GIB-	Phase B S2 terminal of current transformer in the compensating cabinet	
5	GIC+	Phase C S1 terminal of current transformer in the compensating cabinet	
6	GIC-	Phase C S2 terminal of current transformer in the compensating cabinet	

Table 2 - 9 Description of Port 5(Optional) of Secondary Connection

SN	Mark	Description	Remark
1	C1	Control Signal of switching Capacitors	This port is optional, used for controlling capacitor switching Total 16 steps with 12V signal of switching capacitors. Single phase compensation need 3 control signal, 3 phase compensation need 1 control signal.
2	C2	Control Signal of switching Capacitors	
3	C3	Control Signal of switching Capacitors	
4	C4	Control Signal of switching Capacitors	
5	C5	Control Signal of switching Capacitors	
6	C6	Control Signal of switching Capacitors	
7	C7	Control Signal of switching Capacitors	
8	C8	Control Signal of switching Capacitors	
9	+12V	Control Power	
10	C9	Control Signal of switching Capacitors	
11	C10	Control Signal of switching Capacitors	
12	C11	Control Signal of switching Capacitors	
13	C12	Control Signal of switching Capacitors	
14	C13	Control Signal of switching Capacitors	
15	C14	Control Signal of switching Capacitors	
16	C15	Control Signal of switching Capacitors	
17	C16	Control Signal of switching Capacitors	
18	+12V	Control Power	

2.3.5 Connection Diagram of Secondary Terminals of SVG

2.3.5.1 Connection Diagram of Start / Stop Button




Figure 2 - 6 Start and Stop Controlled by Buttons

When SVG is started by a button, there are the above two modes of connection:

- 1) If the inching button is used, DI1 is connected to the normally open button, which is the start button. DI2 is connected to the normally closed button, which is the stop button, as shown in the above left figure.
- 2) If the changeover switch is used, the device is started when it is closed while the device is shut down when it is disconnected, as shown in the above right figure.

2.3.5.2 Operating Condition Indicator Light




Figure 2 - 7 Fault and Operation Indicator Light

When it needs to be connected to external operating condition indicator light, YK1 and YK2 output DC 24V signals through relays. When L1 is on, it indicates that SVG is running, and when L2 is on, it indicates a fault.

2.3.5.3 RS485 Interface




Figure 2 - 8 RS485 Communication Connection Diagram

RS485 communication shall be used when multiple SVG are connected in parallel. when more than eight devices are connected in parallel or the transmission distance exceeds 300 meters, a 120 Ω resistor needs to be connected in parallel to each end of the communication line.

RS485 cable is usually STP cable. One end of the shielding layer is connected to the cabinet floor while the other end is suspended.

For the connection of RS485 for multiple devices, they must be connected hand in hand. Star connection or branch is not allowed. The connection is shown in Figure 2 - 9:




Figure 2 - 9 RS485 Communication Connection Diagram for Multiple Parallel Machines

2.3.5.4 Connection of Current Transformer

DANGER



Dangerous voltage:

If the current transformer is not correctly connected, it may lead to open circuit of CT, damage CT or endanger human body.

- When connecting the current transformer, the secondary side of the transformer must be short-circuited, so as to ensure that the current transformer remains short-circuited until the CT terminal blocks of the device are connected.
- When detaching this device, the secondary side of the transformer needs to be short-circuited.

Please follow the rules listed below:

- The current transformer P1 is close to the system side and P2 is close to the load side.
- S1 of the current transformer is connected to the current input terminal (+), and S2 is connected to the current output terminal (-);
- The input signal of the current transformer must be equipped with a current test terminal to facilitate installation and debugging of the device.
- When more than one device run in parallel, the current transformer must be installed on the load side. When only one device operates independently, the current transformer can be connected to either the system side or the load side, and the load side is preferred.
- The current transformer must be specialized, and the secondary side of the transformer must not be connected to other induction loads in series.

Table 2 - 9 Specifications of Current Transformer

Content	Parameter Value
Rated output current	5 A
Rated output power	$\geq 5.0 \text{ VA}$ (1 ~ 5 units of device(s) running in parallel) $\geq 10.0 \text{ VA}$ (6 ~ 10 units of devices running in parallel)
Precision grade	0.5 (or higher)
Rated input current	CT primary rated current is generally 1.5-2 times of the rated current of the transformer.

(1) Connection of current transformer when single SVG is running

- Filter sampling transformer (external CT) can either be installed on the load side or the system side, and it is preferred to install it on the load side.
- Confirm the installation direction (P1 is close to the system side and P2 is close to the load side.) and phase sequence of the current transformer, so as to ensure the normal operation of the device.




Figure 2 - 10 CT is on the load side when single SVG is in operation (preferred scheme)




Figure 2 - 11 CT is on the system side when single SVG is running




Figure 2 - 12 Connection of current transformer when single SVG is running

Instructions for CT installation and connection:

- The current transformer P1 is close to the system side and P2 is close to the load side (The line enters at P1 and goes out at P2.);
- S1 of the current transformer is connected to the current input terminal (+), and S2 is connected to the current output terminal (-);
- The input signal of the current transformer is equipped with a current test terminal on the cabinet.

(2) Connection of current transformer when multiple SVG are Parallel connection.

The parallel operation of multiple SVG can increase the compensation current value. When connected in parallel, multiple devices share a group of sampling current transformers, and the current signals of the sampling current transformers are connected to all devices connected in parallel, as shown in the following figure. The current transformer can either be installed on the load side (preferred) or the system side. When multiple devices are connected in parallel, a measuring current transformer must be installed in the cabinet to measure the total compensating current of all devices.




Figure 2 - 13 CT is installed on the load side when SVG are running in parallel (preferred scheme)




Figure 2 - 14 CT is installed on the system side when SVG are running in parallel




Figure 2 - 15 Connection of current transformer when SVG are running in parallel

When SVG are connected in parallel, the external sampling CT signals are serially connected to each device in turn, and the connection is shown in Figure 2 - 15.

According to Table 2 - 9 Specification Table of Current Transformers, a current transformer can be connected with up to five devices. When more than five devices are connected in parallel, the current transformer with stronger load output capacity shall be selected or more current transformers shall be provided.

Instructions for CT installation and connection:

- The external current transformer P1 is close to the system side and P2 is close to the load side (The line enters at P1 and goes out at P2.);
- The internal current transformer P1 is close to the system side and P2 is close to the load side (The line enters at P1 and goes out at P2.);
- The secondary side current of the current transformer flows through all devices connected in parallel in turn;
- S1 of the current transformer is connected to the current input terminal (+), and S2 is connected to the current output terminal (-);
- The input signal of the current transformer and the current input signal of all devices are all equipped with current test terminals on the cabinet.

(3) Single SVG + capacitor in hybrid compensation cabinet

In hybrid compensation, SVG needs to control the capacitor for reactive power compensation in addition to completing reactive power compensation, wherein the internal CT measures the total compensating current of all modules and capacitors, and the external CT measures the current of the load side (preferred scheme). If the external CT measures the current of the system side, it must ensure that there is no other current of reactive compensation device in the CT sampling current on the system side.




Figure 2 - 16 The external CT is installed on the load side (preferred scheme)





Figure 2 - 17 Connection Diagram of CT in Hybrid Compensation

2.3.6 Code Switch instruction



Dial up (near the ON side) represents 1, and down represents 0. The code switch corresponds to the 485 communication address shown in the following table.

Code position, Up:1, Down:0				Modular Address
A0	A1	A2	A3	
0	0	0	0	0 (Software set)
1	0	0	0	1
0	1	0	0	2
1	1	0	0	3
0	0	1	0	4
1	0	1	0	5
0	1	1	0	6
1	1	1	0	7
0	0	0	1	8
1	0	0	1	9
0	1	0	1	10
1	1	0	1	11
0	0	1	1	12
1	0	1	1	13
0	1	1	1	14
1	1	1	1	15

2.4 Panel Indicator Light and Debugging Interface of SVG




Figure 2 - 18 Schematic Diagram of Panel Indicator Light of SVG

As the description of status indicator light shown in Figure 2 - 18:

Power - Indication of the power supply of circuit board;

DSP - Indication of the operation of DSP, which flashes with an interval of 1 second.

IGBT - Indication of IGBT fault, when an IGBT fault occurs, it becomes normally on;

HPrt - Indication of a fault, which becomes normally on when faults other than IGBT fault occur.

RUN - Operation indicator light of the device, which is always on when it begins to operate and off when it stands by.

2.5 External LCD Screen of SVG

The LCD screen is connected to No. 2 RS485 Port of the device (terminal mark: 485A2, 485B2).

Chapter III Commissioning Instructions of the Device

3.1 Start and Shutdown of the Device

3.1.1 Starting Mode

The SVG is started in three modes, namely, communication start, automatic start, and DI start, which can all be set through the external LCD screen.

- Communication start: The start of the device can be controlled through the LCD screen.
- Automatic start: The device starts automatically after the device is powered on. For the shutdown caused by a fault or abnormal communication during normal operation, after the fault is removed, the device can be started automatically. In the mode of automatic start, the device can be shut down through the stop button.
- DI start: It can be manually started through the button on the cabinet.

Note: You can only choose one of the three starting modes, and there are no multiple choices, but you can choose more than one modes for shutdown.

3.1.2 Starting Steps

After the device is set to the mode of automatic start, if there is no fault with the device after the power is on, the device will automatically start. If it is set to DI start, it can be started by an external button or the changeover switch. If it is set to the communication start, the device can be started or shut down through the LCD screen.

3.1.3 Shutdown Mode

The device can be shut down in three modes:

- Direct power off of the module (emergency shutdown mode): Directly disconnect the breaker or disconnecter between the device and the mains supply, in which the device is not charged and relevant maintenance can be carried out. (Note: The use of emergency shutdown mode is prohibited in normal operation. Due to the presence of internal electrolytic capacitors, it is strictly prohibited to open the housing of the device within five minutes after the power is cut off).
- Shutdown through LCD screen: Use “on / off” options on LCD screen to shut down the device.
- Shutdown through button: It can be manually shut down through the button on the cabinet.

The LCD screen and button can only shut down the operation of IGBT power devices in the system. However, because the bus and auxiliary power supply of the device are still charged, the

relevant control systems remain standby.

3.2 Display Interface of the Device

Rack Type SVG does not have an LCD screen, **Wall mount type SVG has a 7 inch built-in LCD HMI**, and you can use the supporting external LCD controller(7inch LCD HMI) provided by our company. The LCD controller can display the voltage, current, harmonic, power factor of the system, device output current, etc. in real time. Relevant parameters can be set, such as: Starting mode, CT ratio, compensation method, compensation ratio, etc. It can record and save fault information and relevant data when the device is running.

3.3 Pilot Run Steps

3.3.1 Inspecting Items

1. The grounding of the device housing;
2. Whether the incoming line of the power supply is correct and whether the voltage is normal;
3. Whether CT is correctly installed; whether the installation direction is correct; whether the connection is correct;
4. Whether the control signal line is correct;
5. Whether the communication connection is correct;
6. Whether the design of air holes of the cabinet is reasonable;
7. There are no on-site tools left behind.

3.3.2 Start of the SVG

First, power on the device to check whether the voltage of the device is normal through the display screen.

Set relevant parameters and observe whether the current, power and power factor are correct. If a fault occurs at this time, address it in a relevant way; If no fault occurs and all the measuring data displayed are correct, start the device; when the device begin to operate normally, observe the compensation effect of the device.

3.3.3 Observation of Compensation Effect

The compensation effect of the device can be observed in real time through the LCD screen, and the harmonic current, reactive current, active power of the system can also be measured and the compensation effect of the device can be verified through the power quality analyzer.

Chapter IV Communication Protocol

The modbus communication is used between the device and the LCD screen, and the physical interface adopts RS485 serial port and half-duplex mode. The baud rate of communication is 9600 bps. Relevant settings of modbus communication will be described as follows:

4.1 Communication Settings

- RTU transmission mode;
- 1 start bit;
- 8 data bits, starting with the lowest order bit;
- No odd-even check;
- 1 stop bit;

4.2 Data Type

Table 4.1 Data Type

Data Type	Description
Signed integer_16	16-bit characters, 2's complement
Signed integer_32	32-bit characters, two consecutive Modbus addresses for transmission. The low byte is located at the lower address of Modbus.
Unsigned integer_16	16-bit characters
Unsigned integer_32	32-bit characters, two consecutive Modbus addresses for transmission. The low byte is located at the lower address of Modbus.
Single precision floating point type	32-bit characters, IEEE-754 floating point format

4.3 Function Codes

Table 4.2 Function Codes

Function Codes	Description
03 (0x03)	Read storage register.
06 (0x06)	Write single storage register.

4.4 Communication Protocol

Table 4.3 Communication Protocol

Serial Number	Protocol Address (hexadecimal)	Unit	Meaning
1	0002H	1V	Voltage of Phase A System
2	0003H	1V	Voltage of Phase B System
3	0004H	1V	Voltage of Phase C System
4	0005H	1A	Harmonic Current of Phase A Load
5	0006H	1A	Harmonic Current of Phase B Load
6	0007H	1A	Harmonic Current of Phase C Load
7	0008H	1A	Reactive Current of Phase A Load
8	0009H	1A	Reactive Current of Phase B Load
9	000AH	1A	Reactive Current of Phase C Load
10	000BH	1A	Output Current of Phase A of the Device
11	000CH	1A	Output Current of Phase B of the Device
12	000DH	1A	Output Current of Phase C of the Device
13	000EH	0.001	Power Factor of Phase A Load
14	000FH	0.001	Power Factor of Phase B Load
15	0010H	0.001	Power Factor of Phase C Load
16	0011H	0.001	Power Factor of Phase A System
17	0012H	0.001	Power Factor of Phase B System
18	0013H	0.001	Power Factor of Phase C System
19	0014H	1°C	Temperature of Phase A IGBT
20	0015H	1°C	Temperature of Phase B IGBT
21	0016H	1°C	Temperature of Phase C IGBT
22	0017H	0.1 %	Current THD of Phase A Load
23	0018H	0.1 %	Current THD of Phase B Load
24	0019H	0.1 %	Current THD of Phase C Load
25	001AH	0.1 %	Current THD of Phase A System

Serial Number	Protocol Address (hexadecimal)	Unit	Meaning
26	001BH	0.1 %	Current THD of Phase B System
27	001CH	0.1 %	Current THD of Phase C System
28	001DH	0.1 %	Voltage THD of Phase A System
29	001EH	0.1 %	Voltage THD of Phase B System
30	001FH	0.1 %	Voltage THD of Phase C System
31	0020H	0.1 %	Unbalance Degree of Phase A
32	0021H	0.1 %	Unbalance Degree of Phase B
33	0022H	0.1 %	Unbalance Degree of Phase C
34	0023H	1V	DC Capacitor Voltage VBUS+
35	0024H	1V	DC Capacitor Voltage VBUS-
36	0025H	1A	Active Current of Phase A Load
37	0026H	1A	Active Current of Phase B Load
38	0027H	1A	Active Current of Phase C Load
39	0028H	1A	Current of Phase A System
40	0029H	1A	Current of Phase B System
41	002AH	1A	Current of Phase C System
42	002BH	1A	Current of Phase A Load
43	002CH	1A	Current of Phase B Load
44	002DH	1A	Current of Phase C Load
45	002EH	0.1%	Unbalance Degree of Phase A Load
46	002FH	0.1 %	Unbalance Degree of Phase B Load
47	0030H	0.1 %	Unbalance Degree of Phase C Load

Chapter V Repair and Maintenance

5.1 Routine Maintenance

- 1) Modular design is applied to this device, and you only need to observe whether the data displayed on the LCD screen is correct and whether there is an alarm signal for the routine maintenance.
- 2) Customers whose conditions permit can use infrared thermometer to observe whether there are abnormal high temperature points at the internal temperature points of the device through the air inlet and air outlet. In case of any abnormal conditions, please immediately cut off the power and contact our customer service engineer.
- 3) Frequently check whether the grounding point of the product is reliable.
- 4) Frequently check whether the ventilation of the device is normal and whether the air duct is smooth.

5.2 Precautions


- 1) This device is a heavy-current product. In order to ensure the safety of the maintenance personnel, it is not allowed to contact any live parts of the product during normal operation of the product.
- 2) Due to the isolation of air duct, the dust filter net is not needed in the general application environment, but for severe daily environment, such as high temperature, high humidity and more conductive dust, please contact our product engineer to confirm the specific plan when making a plan.

5.3 Fault judgement


- 1) Common errors: Faults, such as reverse connection of CT lines, reverse connection of phase sequence of power lines and wrong settings of parameters, can be easily found when starting and debugging the device. If the compensation effect is very poor but there is no warning information, please contact our product engineer.
- 2) If the LCD screen displays warning information, please contact our product engineer directly.
- 3) If the power-on device fails to respond, please contact our product engineer directly.

Note: For the sake of your personal safety, no matter what kind of failure occurs, privately dismantling the device shall be not allowed without permission of our company. Products with labels that are easy to tear up and those are easy to be destroyed shall not be under warranty.


Appendix 1 Horizontal Rack Mount SVG



SVG/20kvar Rack type




SVG/30(50)kvar Rack type




SVG/75(100)kvar Rack type

Appendix 2 Wall Mount SVG




SVG/30(50)kvar Wall mount type




SVG/75(100)kvar Wall mount type

Appendix 3 Free landing Cabinet


Static Var Generator Cabinet (100kVAr~400kVAr)



Overall Dimension Drawing (Unit: mm)



Side View,Top View and Bottom View (Unit: mm)



Bottom Entry (Unit: mm)

Remark:

- 1) The cabinet capacity can be arbitrarily combined between 100kVAr and 500kVAr and the cabinet with larger capacity can be customized.
- 2) The maximum capacity of cabinet (800x800x2200 mm) is 400kVAr.
- 3) The maximum capacity of cabinet (1000x1000x2200 mm) is 500kVAr.
- 4) Protection grade of cabinet: IP30 (IP4X can be customized).